
## **Under-belt mounting**



- arm as shown in figure 2.
- 2. Assemble the weight and threaded rod (figure 3).
- 3. Assemble the Y-3 yoke assembly (figure 4).
- 4. Bolt the Y-3 yoke to a mounting beam (not supplied) using the 3/8-16 bolt and lock washer. The Y-3 should be perpendicular to the conveyor belt with the pivot point below the conveyor belt as shown in figure 1, and positioned so the encoder is aligned with the belt. Caution: If the encoder is not aligned with the belt, premature wheel wear will result.
- 5. Adjust the position of the 1.25 lb. weight along the threaded rod. Locating the weight at the end of the rod results in the maximum upward force of the wheels against the belt (this is the normal configuration). The weight can be positioned closer to the encoder along the rod to reduce the upward force.
- 6. Attach the encoder cable so the cord is clear of the pivot point, and with sufficient slack to allow for expected up/down and sideways encoder movement.



602 E. North Street 630-365-7148 Elburn, IL 60119, USA Fax: 630-365-7149 www.photocraftencoders.com

